

REFERENCE GUIDE



Uniden®

Precautions

Before you read anything else,
please observe the following:



Uniden **DOES NOT** represent this unit to be waterproof. To reduce the risk of fire or electrical shock, **DO NOT** expose this unit to rain or moisture.



Changes or modifications to this product not expressly approved by Uniden, or operation of this product in any way other than as detailed by this Reference Guide, could void your authority to operate this product.

TABLE OF CONTENTS

Introduction	1
About Your Radio	1
About Emergency/Weather Alerts	2
About FIPS Codes	3
Obtaining Your Area's FIPS Code(s)	4
Taking Proper Care of Your Radio	5
Unpacking	5
Getting Started	6
Setting Up the WX500 All Hazards/ Weather Radio	6
Battery Backup	8
Controls & Functions	9
Initial Settings	11
Clock Setting	12
Alarm Clock Setting	13
NWS Broadcast Channel Setting	14
FIPS Code Setting	15
Alert Type Setting	17
Backlight Setting	19
Operation	20
Using the All Hazards/Weather Radio	20
Testing the Weather Alert Radio	24
Troubleshooting	25
Technical Specifications	26
One-Year Extended Warranty	27

Introduction

**Getting
Started**

Initial Settings

Operation

Troubleshooting

Specifications

INTRODUCTION

About Your Radio

Traditional weather radios receive NOAA's weather broadcast (usually within a 50-mile radius) then sound an alarm of any emergency code which was transmitted along with the broadcast. This means that people who live outside an affected area are often alerted even when their area is not affected, causing many of them to ignore potentially real emergency/weather warnings that can save lives.

In 1994, the National Oceanic and Atmospheric Administration (NOAA) began broadcasting coded signals called FIPS (Federal Information Processing System) codes along with their standard weather broadcasts from stations in your area. These codes identify an emergency and the specific geographic area (such as a county) affected by the emergency.

The WX500 was developed with the S.A.M.E. (Specific Area Message Encoding) technology. This allows your radio to receive, interpret, and display the information about the codes so you can determine if the emergency might affect your area. Only S.A.M.E. compatible emergency/weather radios are able to take advantage of this new technology.

Each FIPS code identifies a specific geographic area (defined by the National Weather Service), so your radio sounds an alert only when an emergency/weather emergency is declared in those locations. This helps you more efficiently track the emergency/weather conditions in and around your area.

Your new radio is equipped with the following features:

- 7 Preprogrammed National Weather Service Broadcast Channels
- Programmable Emergency/Weather Alert with S.A.M.E. Technology
- Liquid Crystal Display for Alert Description
- Backlit Display
- 20 Programmable Area Codes
- 3 Alert Modes (Display, Tone, Voice)
- Multiple Alert Display Capability
- Alarm Clock with Snooze
- Battery Backup Power Source

About Emergency/Weather Alerts

When the WX500 receives an emergency/weather alert:

- It sounds an alert tone.
- A description of the alert appears.
- An indicator on the front of the radio illuminates.

 NOTE

If the radio receives more than one emergency/weather alert at the same time, it displays information about each alert.


The alert descriptions your radio can display are based on a list of specific emergency/weather alert types published by the NWS. For a list of all the alert descriptions that your radio can display, see NWS Emergency/Weather Alert Event Code descriptions on pages 22 - 23.

Caution: The NWS uses sophisticated models to determine an alert's effective time. However, the end of an alert does not necessarily mean that the related emergency is over.

About FIPS Codes

For the purpose of broadcasting emergency/weather information, the NWS has divided the United States into regions by state and county (or parish, where applicable) then assigned a 6-digit FIPS code to identify each county or parish. For example, the code for Tarrant County, Texas, is 048439.

The first digit in a FIPS code identifies the county subdivision, the next two digits identify the state, and the last three digits identify the county or parish.



NOTE

Most FIPS codes begin with 0, which means that FIPS code represents an entire county. The NWS, however, eventually plans to subdivide some large counties. When that happens, each subdivision will be assigned a digit from 1-9, resulting in codes such as 148439, 248439, and so on.

Your radio can receive all S.A.M.E. alert signals broadcasted within about a 50-mile radius of where you installed it. To receive S.A.M.E. alerts and broadcasts about emergencies/weather occurring only in particular counties within that area, you can program up to 20 FIPS codes into the radio's memory. For example, this lets you avoid hearing an alert that applies to an area within a 50-mile radius but not necessarily to your county or parish.

Obtaining Your Area's FIPS Code(s)

To obtain the FIPS code for the location where you installed your radio, contact the NWS toll free at 1-888-NWR-SAME (1-888-697-7263).

Visit their website: <http://www.nws.noaa.gov/nwr/indexnw.htm>

If you call the NWS, follow the instructions you hear.



If you are close to a county or parish line, you might want to obtain the codes for the nearby counties or parishes.

Hint:

Since you can program up to 20 FIPS codes into the radio's memory, you might want to obtain the codes for other local areas (as long as those areas are within a 50 mile radius of your local NWS broadcast station). That way, you can program those codes into the radio and receive broadcasts covering those locations, too.

Taking Proper Care of Your Radio

- Do not use the radio in high-moisture environments such as the kitchen or bathroom.
- Avoid placing the unit in direct sunlight, near heating elements, or vents.
- Do not plug the radio into an outlet controlled by a wall switch as prolonged periods without power causes the clock to reset.

Unpacking

Carefully check the contents against this list:

- WX500 Radio with built-in telescopic antenna
 - AC Adaptor (Model AC500)
 - Cigarette Lighter Adaptor (Model DC500)
 - This Reference Guide and other printed materials
- ☞ If any items are missing or damaged, contact the Uniden Parts Department at (800) 554-3988. Hours are from 7:00a.m. to 5:00p.m. Monday through Friday, Central Time. We may also be reached at: **www.uniden.com.**
- ☞ Complete and mail your Registration Form immediately.
- ☞ Read this Reference Guide thoroughly before operating the radio.

GETTING STARTED

Setting Up the WX500 All Hazards/Weather Radio



1. Plug the AC adaptor into an outlet and into the WX500. Make sure that the outlet is not controlled by a switch that is turned OFF.
2. Install the 9V Backup Battery by removing the battery compartment cover and snapping the battery onto the terminals.
3. If you would like to program your radio to receive Alerts only for certain areas, determine the SAME codes you need. SAME codes for your area can be found using the National Weather Service toll-free phone number or the NOAA website. Phone: 1-888-NWR-SAME (1-888-697-7263) Web: <http://205.156.54.206/nwr/indexnw.htm> (a branch from <http://www.nws.noaa.gov/nwr>)

NOTE: If the radio will be located close to a county or parish boundary lines, you may want to program SAME codes for the nearby areas.

4. Determine the best Emergency/Weather Channel to use in your area. The best channel for your area is listed on the NOAA website at: <http://205.156.54.206/nwr/indexnw.htm> along with the SAME codes, or at <http://205.156.54.206/nwr/nwrbro.htm>. Or, you can turn the Emergency/Weather Radio and NWR broadcast ON, enter the Menu, and change the CHANNEL until you find the broadcast with the best reception.

Channel Number	NOAA Frequency (MHz)
1	162.550
2	162.400
3	162.475
4	162.425
5	162.450
6	162.500
7	162.525

5. Enter the Menu (*menu* key) and use the ◀, ▶, ▲, ▼ and *select* key if you would like to change the user-programmed settings.


Battery Backup

Battery backup capability allows the WX500 to operate for a limited time when AC power is not available. During AC power loss, all radio features are available, but turning the Emergency/Weather Radio OFF will conserve the battery. Remove the battery if the WX500 will not be plugged in for an extended period of time. Without AC or Battery Backup power, the Clock time will be lost, but all other programmed information will be kept.

WX500 will sound a Low Battery tone at the time that a low battery condition is detected. After the tone, the Low Battery Icon will turn ON to indicate that the Backup Battery needs replacement.



Controls & Functions



- LCD Display** Displays time, channel, frequency, and functions.
- Green Indicator** Indicates that a Statement type of alert broadcast is in effect. Refer to the alert table for details.
- Yellow Indicator** Indicates that a Watch type of alert broadcast is in effect. Refer to the alert table for details.
- Red Indicator** Indicates that a Warning type of alert broadcast is in effect. Refer to the alert table for details.
- Antenna**
- ▲ ▼ Key** With more than one NWR Alert active, forces a change of the display to the next active Alert. During Menu operation, changes the current Menu item.
- ◀ ▶ Key** While setting the Clock time, the Alarm time, or a SAME code during Menu operation, moves to the previous/next field (for example, moving from Minutes to AM/PM).
- menu Key** Enters and exits the Main Menu. Returns to a previous menu while using Sub-menus.
- select Key** During Menu operations, selects the current menu or accepts the current setting.
- weather/snooze** Turns the NWR broadcast (speaker) ON and OFF. When Alarm Clock tones are being heard, stops the tones.

and sets the Alarm Clock tones to start again in 8 minutes (press any other key to reset the Alarm until the alarm time is reached again).

11. *volume/on/off*

Turns the Weather Radio's receiver ON and OFF.
Sets the Volume level for NWR broadcasts. The receiver must be ON in order to use the Weather button or to receive alerts.

12. **Speaker**

NOTE: If the Emergency/Weather Radio is turned OFF while alert messages are active, the active alerts will be deleted.

NOTE: When the WX500 is sounding NWR Alert tones, buttons do not perform their normal functions. Instead, they stop the Alert tones.



1. 14-Segment Characters : Displays Time, Alert information, and Menus
2. Low Battery Icon : Indicates when the Backup Battery needs to be changed.
3. Menu Icon : Indicates Menu programming is active.
4. NOAA Icon : Shown when the Weather Radio receiver is ON, extinguished when the Weather Radio is OFF.
5. Tone Icon : Indicates that the Alert Method is set to TONE.
6. Voice Icon : Indicates that the Alert Method is set to VOICE.
7. Alarm Icon : Indicates that the Alarm Clock is set to sound Alarm tones.

If the NOAA icon is ON but the TONE and VOICE icons are OFF, the Weather Receiver is available (ON) for listening to NWR broadcasts and the Alert Method is DISPLAY (Alerts will be displayed, but no Alert tones will be sounded).

Initial Settings

There are six menu options that you must set up prior to proper operation.

To do this, press the *menu* key. Use the ▲/▼ keys to change the six menu options.

Setting	Default
Clock Time (TIME)	12:00 AM
Alarm (ALARM)	OFF
Channel (CHANNEL)	1 (162.550 MHz)
SAME code (SAME SET)	ANY
Alert type (ALT TYPE)	VOICE
Backlight mode (LIGHT)	SAVE

To exit the menu mode, press *menu* repeatedly.

Each of these options are described in more detail following this introduction.

Clock Setting

When you first apply power or when there is a power outage without the battery backup, the current time on the display will not be correct.

To set the current time:

1. Press *menu*.
2. *TIME* appears on the display.



3. Press *select*.
4. Enter the time by pressing the ◀, ▶, ▲, and ▼ keys.



5. Press *select* to complete the entry. The display goes back to the Menu mode.

Alarm Clock Setting

As an additional feature, the WX500 has an audible alarm clock. Before setting this feature, set the clock to the current time. (See page 12.)

1. Press the *menu* key.
2. Press $\blacktriangle/\blacktriangledown$ until *ALARM* appears.
3. Press *select* for setting the Alarm Clock.

4. Press $\blacktriangle/\blacktriangledown$ to choose the Alarm Clock Setting. If you do not want to set the Alarm Clock, select *OFF*. The display goes back to the menu mode.



5. If you select *ON*, enter the time by pressing the $\blacktriangle/\blacktriangledown$ keys. To scroll more quickly (in 15 minute increments), press and hold $\blacktriangle/\blacktriangledown$ for more than 5 seconds.



6. To move to the next digit press $\blacktriangle/\blacktriangledown$.
7. To exit press the *menu* key.

NWS Broadcast Channel Setting

Your radio is preprogrammed with the seven National Weather Service broadcast frequencies (Channel 1-7). Depending on your location, you may be able to receive more than one channel with clear reception.

CH No.	Frequency (MHz)
1	162.550
2	162.400
3	162.475
4	162.425
5	162.450
6	162.500
7	162.525

The first time you use your radio, Channel 1 (162.550 MHz) is automatically set as your emergency/weather channel. Depending on your location, you may be able to receive this channel. To check or change channels, perform the following steps.

1. Turn the **on/off/volume** control until it clicks. The NOAA icon will appear in the display.
2. Press **weather/snooze**.
3. Adjust the volume control to a comfortable listening level. You may hear the emergency/weather broadcast on the initially selected channel. If not or if you wish to select another channel, continue on. Otherwise stop here. Your channel is set.
4. Press **menu**.
5. Press **▲/▼** until **CHANNEL** appears.
6. Press **select**.
7. Press **▲/▼** to scroll through the list of channels. The channel number and the corresponding frequency appear in the display. If you receive more than one channel, select the one that has the clearest audio.
8. Press **select** again to complete the entry.

FIPS Code Setting

The 6-digit Federal Information Processing System (FIPS) code established by the National Weather Service (NWS) identifies geographic areas in the United States. Programming FIPS code is necessary to receive S.A.M.E. alerts about emergencies/weather occurring in a particular area.

To set FIPS codes:

1. Press **menu** and toggle $\blacktriangle/\blacktriangledown$ until *SAME SET* appears in the display.
2. Press **select**.
3. Press $\blacktriangle/\blacktriangledown$ to select *SINGLE*, *MULTIPLE*, or *ANY*.
or:
 - If you select *ANY*, press **select**. This completes the entry. The display returns to menu mode.
 - If you select *SINGLE*,
 - a) Press **select**. Then enter the FIPS code that you want to be monitoring.
 - b) Press **select** and the display returns to menu mode.
 - If you select *MULTIPLE*,
 - a) Press **select**. *SAME 1* appears in the display. If you do not want to see or change the first FIPS code, use $\blacktriangle/\blacktriangledown$ to choose another location.
 - b) Press **select** again and the first digit of the FIPS code starts flashing, indicating that the code is ready to be edited.
 - c) Press the $\blacktriangle/\blacktriangledown$, $\blacktriangleleft/\blacktriangleright$ keys to enter the code and press **select** again.
 - d) Repeat the above steps in any or all memory locations using the $\blacktriangle/\blacktriangledown$ to select another location.
 - e) To exit this mode, press **menu** key until *SAME SET* appears in the display.

Option Description:

- ANY FIPS** When this option is selected, your radio receives the alert signals of any FIPS codes whether you have programmed them or not.
- SINGLE** When this option is selected, your radio only receives the alert signals corresponding to the FIPS code that you enter.
- MULTIPLE** When this option is selected, your radio receives the alert signals corresponding to the FIPS code that you program in any of the 20 memory locations.

6. To turn OFF the radio, turn the *on/off/volume* control until it clicks. Your radio will continue to function as an Alarm Clock. The selected settings remain for the next time the radio is turned ON

Alert Type Setting

When the All Hazards/Weather Radio is ON, this setting determines how WX500 will communicate screened NWR Alert messages. For all three selections, the 5 most recent Alerts, along with Severity and Time of the Message Expiration, will be shown on the display.

DISPLAY: Upon receiving a screened NWR Alert, only the Alert and Alert Severity displays will be affected. No Alert tones will sound and the broadcast will not be heard unless you press the *weather/snooze* key.

VOICE: Upon receiving a screened NWR Alert, an alert tone will sound for about 8 seconds. After the alert tone, the WX500 will automatically turn ON the emergency/weather broadcast (speaker). You will hear the broadcast until the NWR End-of-Message code is received or until you turn the broadcast OFF. The WX500 automatically selects the VOICE Alert Type the first time you turn it ON.

TONE: Upon receiving a screened NWR Alert, an alert tone will sound for up to 15 minutes. A press of any key will stop the Alert tone. The broadcast will not be heard unless you press the *weather/snooze* key.

To change the Alert Type setting, see the following steps.

1. Press the *menu* key
2. Press $\blacktriangle/\blacktriangledown$ until *ALT TYPE* appears on the display.
3. Press the *select* key.
4. Press $\blacktriangle/\blacktriangledown$ to choose *TONE*, *VOICE* or *DISPLAY*.
5. Press the *select* key again.
6. Press *menu* to exit.

The Alert Type setting you selected will determine the Alert Type icon on the display. If you selected the *TONE* Alert Type alert, the following icon will be displayed.



If you selected the *VOICE* Alert Type alert, the following icon will be displayed.



If you selected the *DISPLAY* Alert Type alert, the following icon will be displayed.



To silence the tone, press any key.

Backlight Setting

The initial setting for the display backlight is *SAVE*, which means the backlight stays on for 10 seconds. You can change this setting by following the steps below:

1. Press the *menu* key.
2. Press $\blacktriangle/\blacktriangledown$ until *L IGH T* appears on the display.
3. Press the *select* key for the Backlight Settings.
3. Press $\blacktriangle/\blacktriangledown$ to select *OFF*, *SAVE*, *CONST-LO*, or *CONST-HI*.

OFF The LCD backlight will never be illuminated.

SAVE The LCD backlight will turn on (bright) for 10 seconds following a new NWR Alert or following a user key-press.

CONST-LO The backlight will stay on dimly most of the time but will switch to bright for 10 seconds following a new NWR Alert or following a key press.

CONST-HI The backlight will always stay on brightly.

4. Press the *select* key.
5. To exit the menu mode, press *menu*.



The CONST-LO and CONST-HI settings can significantly affect battery life while operating with the BATTERY ONLY. If the adaptor power is lost, it is recommended to change the Backlight mode to OFF or SAVE.

OPERATION

Using the All Hazards/Weather Radio

Your radio functions as an all hazards/weather warning radio. This is especially useful when your area is expecting severe weather conditions any time of day. It emits a loud tone whenever your local NOAA weather station broadcasts a severe emergency tone. You have the option of listening to the emergency/weather broadcast or not. Even though you may not be listening to the broadcast, the radio still responds to the emergency tones from the local weather station.

To turn ON the emergency/weather alert radio:

1. Turn the **on/off/volume** until it clicks. The NOAA icon appears in the display.
2. Press **weather/snooze** until you hear the weather broadcast.

OR

If you do not want to listen to the emergency/weather broadcast, press **weather/snooze** again. The receiver is actually still ON but the audio is muted.

3. Make sure you adjust your volume control to a comfortable listening level. If you have set the Alert Type to **VOICE**, the volume level of the voice broadcast, when it comes on, will be set correctly.

 NOTE

The volume control only adjusts the audio of the broadcast, not the siren volume.

4. The last five, non-expired, Alerts will scroll across the LCD one at a time.



Each Alert will be displayed with its appropriate Severity indicator and with the time until the Alert message expires.



You can force the WX500 to quickly skip to the previous/next Alert by using the ▲/▼ keys. Stop Alert tones by pressing any key.



The NWS uses sophisticated models to determine an Alert's expiration time. The expiration of an Alert, however, does not necessarily mean that the related emergency is over. This is particularly true for longer duration Alerts because Alert expiration times are limited to 6 hours in the NWS protocol.

The following is a list of Event codes transmitted by the National Weather Service. When a specific Event code is received, this chart indicates the displays as they alternately appear on the display with the corresponding Alert Type indicator, and the Alert Type tone of the siren.

Event Codes

Event Code	Display 1	Display 2	Display 3	LED	Alert Siren
AVW	AVALANCH			Red	Warning Siren
AVA	AVALANCH			Yellow	Watch Siren
BZW	BLIZZARD			Red	Warning Siren
CDW	CIVIL	DANGER		Red	Warning Siren
CDA	CIVIL	DANGER		Yellow	Watch Siren
CEM	CIVIL	EMERGENC	TUNE TV	Red	Warning Siren
CFW	COASTAL	FLOOD		Red	Warning Siren
CFA	COASTAL	FLOOD		Yellow	Watch Siren
EAN	EMERGENC	ACTION		Red	Warning Siren
EAT	EMERGENC	ACTION	TERMINAT	Red	Warning Siren
EVI	EVACUATE	IMMEDIAT		Red	Warning Siren
FRW	FIRE			Red	Warning Siren
FFS	FLASH	FLOOD		Green	Statement Siren
FFW	FLASH	FLOOD		Red	Warning Siren
FFA	FLASH	FLOOD		Yellow	Watch Siren
FLS	FLOOD			Green	Statement Siren
FLW	FLOOD			Red	Warning Siren
FLA	FLOOD			Yellow	Watch Siren
HMW	HAZARD	MATERIAL		Red	Warning Siren
HMA	HAZARD	MATERIAL		Yellow	Watch Siren
HWW	HIGH	WIND		Red	Warning Siren
HWA	HIGH	WIND		Yellow	Watch Siren
HLS	HURRICAN			Green	Statement Siren
HUW	HURRICAN			Red	Warning Siren
HUA	HURRICAN			Yellow	Watch Siren
IEW	IMMEDIAT	EVACUATE		Red	Warning Siren
LEW	LAW	ENFORCE		Red	Warning Siren

Event Code	Display 1	Display 2	Display 3	LED	Alert Siren
LAE	LOCAL	AREA	EMERGENC	Red	Warning Siren
NHW	NATIONAL	HAZARD		Red	Warning Siren
NIC	NATIONAL	INFO	CENTER	Red	Warning Siren
NPT	NATIONAL	PERIODIC	TEST	Green	Statement Siren
DMO	DEMO	MESSAGE		-	None
RHW	RADIOLOG	HAZARD		Red	Warning Siren
RHA	RADIOLOG	HAZARD		Yellow	Watch Siren
RWT	WEEKLY	TEST		-	Statement Siren
RMT	MONTHLY	TEST		-	Statement Siren
SVR	SEVERE	THUNDER		Red	Warning Siren
SVW	SEVERE	THUNDER		Red	Warning Siren
SVA	SEVERE	THUNDER		Yellow	Watch Siren
SVS	SEVERE	WEATHER		Green	Statement Siren
SPW	SHELTER	IN-PLACE		Red	Warning Siren
SMW	SPECIAL	MARINE		Red	Warning Siren
SPS	SPECIAL	WEATHER		Green	Statement Siren
TOR	TORNADO			Red	Warning Siren
TOW	TORNADO			Red	Warning Siren
TOA	TORNADO			Yellow	Watch Siren
TSW	TSUNAMI			Red	Warning Siren
TSA	TSUNAMI			Yellow	Watch Siren
VOW	VOLCANO			Red	Warning Siren
VOA	VOLCANO			Yellow	Watch Siren
WSW	WINTER	STORM		Red	Warning Siren
WSA	WINTER	STORM		Yellow	Watch Siren
??E	UNKNOWN	TUNE TV		Red	Warning Siren
??A	UNKNOWN	TUNE TV		Yellow	Watch Siren
??W	UNKNOWN	TUNE TV		Red	Warning Siren
??S	UNKNOWN	TUNE TV		Green	Statement Siren

Testing the Weather Alert Radio

NWR stations conduct regular tests of Alert broadcasting. Tests normally occur on Wednesdays between 10AM and 12PM unless threatening weather is occurring. Your local station can be contacted to find out exact dates and times of tests.

You should make sure your WX500 receives these Test Alerts in its installed location. This is very important because an emergency alert broadcast might not trigger your radio even when it seems to be receiving broadcasts fairly clearly. If broadcast signals are too weak, you might be able to receive Alerts in one part of a building but not another.

TROUBLESHOOTING

If your WX500 radio is not performing properly, try the following steps. If you are still unable to resolve the problem, contact your place of purchase or call customer service at (800) 297-1023.

Problem	Solution
WX500 won't power up.	Check the connections at both ends of the AC Adapter. Turn on the wall switch of your room. You could be using an outlet controlled by the wall switch. Move the AC Adapter to another wall outlet. Move the antenna.
Poor reception.	Relocate the radio. Check if a stronger station is available in your area. You may be in a fringe area. Check reception.
No Alert messages received.	Make sure the on/off/volume dial is turned ON. If you have programmed a S.A.M.E. (FIPS) code, check that it is correct.
Alerts received for all / unwanted counties/parishes	Make sure that the Alert screening method is SINGLE or MULTIPLE and that the S.A.M.E. codes are correct. 'Erase' unwanted area codes by setting them to something like '000000' or '999999'.
Weather broadcast is not heard when <i>weather/snooze</i> button is pressed.	Make sure the on/off/volume dial is turned ON. Check that the channel is set to an active station.

TECHNICAL SPECIFICATIONS

Frequency Coverage (MHz):	Channel 1:	162.550
	Channel 2:	162.400
	Channel 3:	162.475
	Channel 4:	162.425
	Channel 5:	162.450
	Channel 6:	162.500
	Channel 7:	162.525
Receiving Sensitivity (at 12 dB SINAD):		0.35 μ V
FIPS Decode Sensitivity @ Dev. \pm 4.5 kHz		
Deviation/90 % Success Rate:		0.40 μ V
Signal & Noise Ratio:		40 dB
Channel Selectivity:		45 dB
Audio Output Power @ 10% THD:		250 mW
Power Requirements:		Use AC500 (adaptor included) with 120 V AC (\pm 10%) 60 Hz or DC cigarette lighter adaptor
Battery Back-up:		One 9-Volt Alkaline Battery (not included)
Antenna:		Telescopic Rod Antenna (built-in)
Dimensions:		127 (W) x 126 (D) x 48 (H) mm
Weight:		245 g without AC ADAPTOR and 9 V Battery

Specifications are typical; individual units might vary.
Specifications are subject to change and improvement without notice.

ONE-YEAR EXTENDED WARRANTY

Important: Evidence of original purchase is required for warranty service.

WARRANTOR: UNIDEN AMERICA CORPORATION (“Uniden”)

ELEMENTS OF WARRANTY: Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below.

WARRANTY DURATION: This warranty to the original user shall terminate and be of no further effect one year after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner’s manual for this product.

STATEMENT OF REMEDY: In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY DOES NOT COVER OR PROVIDE

FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

LEGAL REMEDIES: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void outside the United States of America.

PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY: If, after following the instructions in the reference guide you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor at:

Uniden America Corporation
Parts and Service Division
4700 Amon Carter Blvd
Fort Worth, TX 76155
(800) 297-1023, 8 a.m. to 5 p.m., Central Time,
Monday through Friday

THANK YOU
FOR PURCHASING THIS UNIDEN PRODUCT!

Uniden®

**©2002 Uniden America Corporation
OMWX500**

All rights reserved • Printed in China

Covered under one or more of the following U.S. patents:

4,597,104 4,627,100 5,438,688

5,448,256 5,530,296 5,548,832

5,598,430 5,600,223 5,642,424